


For 2GIG Panel Strobe/Siren

Need help? Give us a call.
1-877-826-5443

Enroll

STEP 1

- a. Move the 2GIG Panel within 5 feet of the Strobe/Siren.
- b. **Press** **SERVICES** from the home screen of the 2GIG panel.
- c. **Select** **Z-WAVE**.
- d. **Press**  on the bottom right corner and enter the Installer Code.
- e. **Select** **ADD DEVICE**. The panel will say "discovering devices."

STEP 2

- a. On the back of the Interior Strobe/Siren **press** and **release** the program switch twice.
- b. The panel should discover the device and show "querying device information." Once the node ID and manufacturer shows the Strobe/Siren will be finished learning in.

Install

STEP 1

Avoid mounting the device in areas where it will be exposed to moisture or in an area where a temperature range of 32 to 120F cannot be met.

STEP 2

Avoid mounting the device on metal or in an area with large quantities of metal or electrical wiring as this can cause signaling issues for the device.

STEP 3

Install the device within 20 feet of the control panel or within 20 feet of a z-wave repeater.

STEP 5

Make sure the device can be plugged into a 110V outlet where it is installed.