

# GC-TBZ48 for IQ2 Panel Thermostat

Need help? Give us a call.  
**1-877-826-5443**

## Enroll

---

### STEP 1

- a. Move the IQ2 Panel within 5 feet of the Thermostat.
- b. On the IQ Panel **swipe down** on the home screen.
- c. Go to **SETTINGS** and then **ADVANCED SETTINGS**.
- d. **Enter** the Installer code.
- e. Go to **INSTALLATION**.
- f. Go to **DEVICES**.
- g. Go to **Z-WAVE DEVICES**.
- h. **Press** **ADD DEVICE** and **press** **PAIR**.

### STEP 2

- a. **Press** any button on the thermostat to take it out of sleep mode.
- b. **Press** and **hold** FAN button for 5 seconds. SETUP will be displayed in the status display line.
- c. **Scroll** to "Z-Wave" using ▲▼ buttons. **Press** **SELECT**.
- d. When prompted by the Panel, press the **YES** button in the Z-Wave Install screen.
- e. Press **SELECT** to add thermostat to network.
- f. Display line should flash WAIT then SUCCESS if Z-Wave connect on is made.
- g. If Thermostat does not connect to the Panel, WAIT then FAIL will flash in status display line.
- h. If thermostat fails to connect, repeat steps c through h in Step 1 above.