


For 2GIG Panel Panic Button Remote

Need help? Give us a call.
1-877-826-5443

Enroll

- a. **Select**  on the bottom right hand corner of the home screen.
- b. **Enter** the installer code.
- c. **Select** **SYSTEM CONFIGURATION**.
- d. **Press** **▶** until you come to a free sensor space.
- e. **Press** **▼**.
- f. **Select** RF Sensor Type 07–24-hour audible alarm. **Press** **▼**.
- g. **Select** equipment type 1–contact. **Press** **▼**.
- h. **Enter** 0868 for 2GIG Panic Button Remote. **Press** **▼**.
- i. **Press** **SHIFT** then **LEARN**. Trigger the sensor by **pressing** and **holding** the button on the sensor for approximately 2 seconds. **Press** **OK** then **press** **▼**.
- j. **Set** the equipment age to “new.” **Press** **▼**.
- k. **Set** the loop number to 1 by pressing the **▶**. **Press** **▼**.
- l. **Set** the dialer delay to **DISABLED**. **Press** **▼**.
- m. Choose the **VOICE DESCRIPTOR** by **pressing** **INSERT** and **entering** the corresponding code for each name. **Press** **▼**.
- n. **Set** the reports to **DISABLED**. **Press** **▼**.
- o. **Set** supervised to **ENABLED**. **Press** **▼**.
- p. **Press** **▶** to change the chime to **VOICE ONLY**. **Press** **▼**.
- q. **Press** **SKIP**. **Press** **END**. Make sure the “save changes” box is checked and **press** **EXIT**.

Install

OPTION 1

The Panic button can be used with the supplied wristband, lanyard, car-visor clip, or belt clip.

OPTION 2

It can also be secured permanently by inserting it in to the wall-mount and then using adhesive tape to mount it in a convenient location.