


PAD1 Wireless Keypad

Need help? Give us a call.
1-877-826-5443

Mount



STEP 1

Simultaneously press both tabs on top of the keypad to separate mounting plate from main keypad. Ensuring mounting plate is level, place plate in desired location and secure it with 4 screws in provided holes (fig 1).




fig 2

STEP 2

To connect batteries, remove both battery pull tabs located near the metal clips (fig 2), then reattach keypad by inserting bottom onto mounting plate first. Tilt it upward to snap the keypad into place.

Replacing Batteries

STEP 1

Remove the keypad from mounting plate. Place small flathead screwdriver in slot between metal clip (fig 2) and battery. Twist screwdriver slightly while holding back black plastic edges.

STEP 2

Insert replacement batteries (CR2032) with the + sign facing out (fig 2).