GB1

Glass Break Detector

for GC3 Panel

Need help? Give us a call.
1-877-826-5443

Enroll

STEP 1
Select SYSTEM SETTINGS **>** ***Enter*** Master Code **>** Scroll Down **>** ***Select*** INSTALLER TOOLBOX **>** ***Enter*** 2010.

STEP 2
Select SYSTEM CONFIGURATION **>** ***Select*** WIRELESS ZONES **>** Scroll Down until you see the desired sensor or next free zone **>** ***Select*** EDIT ZONE.

STEP 3
Select "03-Perimeter"**>** ***Select*** the down arrow.

STEP 4
Enter "0864" to show "0864 - 2GIG Glass Break Detector" **>** ***Select*** the down arrow.

STEP 5
Either enter the 7 digit TXID # or ***select*** LEARN and remove the back plate then ***select*** ACCEPT **>** ***Select*** the down arrow.

STEP 6
Select "New" **>** ***Select*** down arrow.

STEP 7
Select "Loop 1" **>** ***Select*** down arrow.

STEP 8
Select ENABLED **>** ***Select*** the down arrow.

STEP 9
Select EDIT VOICE DESCRIPTOR and choose from list at top or type desired word. If word is available it will show at the top **>** ***Select*** DONE **>** ***Select*** down arrow.

STEP 10
Select ENABLED **>** ***Select*** the down arrow.

STEP 11
Select ENABLED **>** ***Select*** the down arrow.

STEP 12
Select if you would like a chime or voice or none.

STEP 13
Select NEXT ZONE if you have other sensors to program or ***select*** RETURN TO SYSTEM CONFIGURATION if you are done then ***select*** the left arrow then ***select*** SAVE.